### imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



### Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



## IIDASH PANAMSE®

**MOUNTING LOCATION:** Right side of radio J R **TOOLS REQUIRED:** 

Dash Tool, Hook Tool Phillips Screwdriver HARDWARE INCLUDED: (3)A - #8x9/16"Needle Pt. Screw

**CELL PHONE & MEDIA MOUNT** 

**INSTALLATION INSTRUCTIONS** 

PART#: 751371307

MFG: TOYOTA/FORD/MERCURY/MAZDA

MODELS & YEARS: TOYOTA - Tundra 07-13, Sequoia 08-12 FORD-Edge07-10, Escape08-12 **MERCURY-Mariner 08-11** MAZDA-Tribute 08-11(Pg.2)

#### Start Here for Toyota Tundra/Sequoia:

STEP#1: With hook tool, insert it deep into the upper right corner of the Instrument Panel & Audio-Video bezel. Pull to release (1) clip by the air vent at the top. Continue to pull to release (1) clip by the fan control, 4WD switch is included with the bezel. With hook tool release the climate control by inserting hook tool into upper left corner, pull to release (1) clip. Continue releasing climate control and a total of (4) clips.

STEP #2: With hook tool/Dash tool remove the cubby below the climate control by inserting it between the climate control and top of the cubby bezel, pull to release (4) clips. Work your way to the bottom of the bezel to release (2) more clips. Pull bezel straight out to remove cubby.

**STEP #3:** Remove the radio by removing (4) 10mm bolts below the radio. Pull out the radio to release (3) clips on top of the radio. Set radio down onto a cloth.

STEP #4: Place InDash by PanaVise Mount on the right side of the radio cavity into the slot it fits best. See Picture. Install the (3) supplied screws.

STEP#5: Replace the radio/climate control/cubby bezels, and then snap in the Instrument Panel starting at the bottom. INSTALLATION IS COMPLETE, ENJOY YOUR NEW INDASH BY PANAVISE MOUNT.



**Final Installation Picture** 



InDash Installation Location

#### 751371307 Page 1 of 2

**ADVISEMENT** 

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for lefthand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Bezel released-Note AC Knot



AC Bezel released w/ Dash Tool



(4) Radio bolts Location



There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.

# I I D A S H PANAMSE®

MOUNTING LOCATION: Right side of radio J R

**TOOLS REQUIRED:** Dash Tool, Hook Tool Phillips Screwdriver **HARDWARE INCLUDED:** (3)A - #8x9/16"Needle Pt. Screw CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 751371307 MFG: TOYOTA/FORD/MERCURY/MAZDA MODELS & YEARS: TOYOTA - Tundra 07-13, Sequoia 08-12 FORD - Edge 07-10, Escape 08-12 MERCURY-Mariner 08-11 MAZDA-Tribute 08-11

#### Start Here for Ford Edge:

**STEP #1:** With hook tool, remove the bezel that goes from the top of the dash (with tray), down to, and includes the climate control and air vents. Start at the bottom to release (2) clips. Continue up to the top of the bezel releasing a total of (10) clips.

**STEP #2:** Place the InDash by PanaVise Mount on the right side of the vent cavity. Install the (3) screws supplied.

**STEP #3:** Replace the radio/climate control/air vent bezel.



Final Installation Picture - Edge



InDash Installed, Mounting Location - Edge

**Start Here for 2008's, Ford Escape, Mercury Mariner, Mazda Tribute : STEP #1:** With hook tool, remove air vent assembly by inserting hook tool/dash tool into the side and pull to release (4) clips. Set assembly aside.

**STEP #2:** Place InDash by PanaVise Mount on the right side of the air vent cavity and install the (3) supplied screws. Replace the radio/climate control/air vent

bezels.



Final Installation Picture -08 Mariner, Escape, Tribute

Mountl Installed Location 08 Mariner, Escape, Tribute

751371307

Page 2 of 2

#### \* \* ADVISEMENT \* \*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for lefthand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Radio Climate Control, Air Vent, Bezel Removed



Air Vent Assembly Removed



Suggested Mounting Location

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.